P.O. BOX 496 BEAVER, PA 15009 PH: 724-775-7926 FX: 724-775-5283 www.c3controls.com e-mail: info@c3controls.com

C3CONTrols Installation Instructions

& Dimensional Drawings IL 100187



REV 1

EXTERNAL OPERATING HANDLE



10 - Then mount the gasket (Item 11) and bezel (Item 12) on the outside of the enclosure panel (Item 10) securing the mounting bracket assembly (Item 9), gasket (Item 11) and bezel (Item 12) with the mounting screws (Item 13). The bezel (Item 12) should be installed so that the script plate locating nub (Item 12a) is opposing the 'ON' position. 11 - Install the script plate (Item 14).

12 - Install operator handle (Item 15) and secure with operating handle assembly screw (Item 16).

INSTALLATION MOUNTING DIMENSIONS AND SHAFT CUTTING INSTRUCTIONS (DIMENSIONS ARE IN MM)



Product installation instructions and dimensional drawings may be downloaded from our website, www.c3controls.com.



CONFORMITY TO STANDARDS UL 508, 60947-4-1 CSA C22.2 No. 14 IEC 60947-1 & 60947-4-1 CERTIFICATIONS UL File #: E187641 (Guide NLRV, NLRV7), E312106 (Guide NKJH, NKJH7) CE Marked (per EU Low Voltage Directive 2006/95/EC & RoHS Directive 2011/65/EU)