



Customer to
make connections.
See pg 2 for details.



VIEW1 - Enclosure With Cover On
SCALE 5/8

Customer to
make connections.
See pg 2 for details.




VIEW2 - Enclosure With Cover Off
SCALE 5/8



WARNING


- * Disconnect Power before proceeding with any work on this equipment.
- * Installation and maintenance by technical personnel only.
- * Installation of c3controls product must be in accordance with the NEC (U.S. National Electrical Code) regulations or local codes/standards per your application.
- * Any violation of these safety requirements could result in a personal injury and/or result in damage to the equipment.



make connections

VIEW3 - Enclosure With Cover On
SCALE 1 : 1


RECEIVER/TRANSMITTER/CONTROLLER (UL Listing) Conductors only.




Customer to make
connections.
120VAC

VIEW4 - PCBA Connections
SCALE 1 : 1


VIEW7 - Enclosure Top View
SCALE 1/2



VIEW5 - Enclosure Back View
SCALE 1/2



VIEW6 - Enclosure Bottom View
SCALE 1/2



UNDERVIEWED 90 DEG