



**TRIP CHARACTERISTICS**

320-B1\*\*\*, 320-B2\*\*\*, 320-B3\*\*\* & 320-B4\*\*\*



320-B5\*\*\*



NOTE: \*\*\*Represents the overload relay current adjustment range code. Refer to page 6.